



Installation, Start-Up and Service Instructions

CONTENTS

	Page
SAFETY CONSIDERATIONS	1
INSTALLATION	1-17
General	1
Step 1 — Complete Pre-Installation Checks	1
Step 2 — Rig and Mount Unit	1
Step 3 — Complete Refrigerant Piping Connections	10
Step 4 — Complete Electrical Connections	11
PRE-START-UP	18, 19
START-UP	19-21
SEQUENCE OF OPERATION	21, 22
SERVICE	22-27
TROUBLESHOOTING	28, 29
START-UP CHECKLIST	CL-1, CL-2

SAFETY CONSIDERATIONS

Installing, starting up, and servicing air-conditioning equipment can be hazardous due to system pressures, electrical components, and equipment location (roofs, elevated structures, etc.).

Only trained, qualified installers and service mechanics should install, start-up, and service this equipment. Untrained personnel can perform basic maintenance functions such as cleaning coils. All other operations should be performed by trained service personnel.

When working on the equipment, observe precautions in the literature and on tags, stickers, and labels attached to the equipment.

Follow all safety codes. Wear safety glasses and work gloves. Keep quenching cloth and fire extinguisher nearby when brazing. Use care in handling, rigging, and setting bulky equipment.

⚠ WARNING

Before installing or servicing system, always turn off main power to system and install lockout tag on disconnect. There may be more than one disconnect switch. Electrical shock can cause personal injury.

INSTALLATION

General — The split system heat pump units described in this book should only be used with the 40RMQ indoor packaged air handler sections.

Step 1 — Complete Pre-Installation Checks

UNCRATE UNIT — Remove unit packaging except for the top skid assembly, which should be left in place until after the unit is rigged into its final location.

INSPECT SHIPMENT — File claim with shipping company if shipment is damaged or incomplete.

CONSIDER SYSTEM REQUIREMENTS

- Consult local building codes and National Electrical Code (NEC, U.S.A.) for special installation requirements.
- Allow sufficient space for airflow clearance, wiring, refrigerant piping, and servicing unit. See Fig. 1-3 for unit dimensions. Figure 4 shows typical component locations for 38AQS016 units.
- Locate unit so that outdoor coil airflow is unrestricted on all sides and above.
- Unit may be mounted on a level pad directly on the base channels or mounted on raised pads at support points. See Tables 1A-1D for unit operating weights.

Step 2 — Rig and Mount Unit

⚠ CAUTION

Be sure unit panels are securely in place prior to rigging. Be careful rigging, handling, and installing unit. Improper unit location can cause system malfunction and material damage. Inspect base rails for any shipping damage and make sure they are fastened securely to unit before rigging.

RIGGING — These units are designed for overhead rigging. Refer to rigging label for preferred rigging method. Spreader bars are not required if top crating is left on unit. All panels must be in place when rigging. As further protection for coil faces, plywood sheets may be placed against sides of unit, behind cables. Run cables to a central suspension point so that angle from the horizontal is not less than 45 degrees. Raise and set unit down carefully.

If it is necessary to roll the unit into position, mount the unit on field-supplied rails placed lengthwise under the unit using a minimum of 3 rollers. Apply force to the rails, not the unit. If the unit is to be skidded into position, place it on a large pad and drag it by the pad. Do not apply any force to the unit.

Raise from above to lift unit from the rails or pad when unit is in final position.

After unit in position, remove all shipping materials and top crating.

LOCATE UNIT — For service access and unrestricted airflow, provide clearance on each end and side of unit. Position unit so that there is unrestricted airflow above unit.

NOTE: Before mounting unit, remove holddown brackets and release skid.

If conditions or local codes require unit to be fastened to pad, use the mounting holes in the base rails.

MOUNT UNIT — The unit may be mounted on a solid, level concrete pad, on accessory mounting legs, or on field-supplied raised supports at each mounting position. (Note that mounting hardware is field supplied.)

Bolt unit securely to pad or supports after unit is in position and is level. Be sure to mount unit level to ensure proper oil return to compressors. Mounting holes on unit can be used to secure unit to vibration isolators, if required.




Fig. 1 — 38AQ007 Unit Dimensions




Fig. 2 — 38ARQ008,012 Unit Dimensions

UNIT	ELECTRICAL CHARACTERISTICS	ALUMINUM COIL												COPPER COILS											
		Std. Unit Wt.		Corner W		Corner X		Corner Y		Corner Z		Center of Gravity [mm (in.)]		Std. Unit Wt.		Corner W		Corner X		Corner Y		Corner Z		Center of Gravity [mm (in.)]	
		lb	kg	lb	kg	lb	kg	lb	kg	lb	kg	X	Y	lb	kg	lb	kg	lb	kg	lb	kg	lb	kg	X	Y
38ARQ008	208/230-3-60, 460-3-60	464	210	120	54	142	64	108	49	94	43	812.8 [32.00]	660.4 [26.00]	585	256	135	61	173	79	144	65	113	51	850.9 [33.50]	635.0 [25.00]
38ARQ012	208/230-3-60, 460-3-60, 575-3-60	506	230	120	54	168	76	127	58	91	42	889.0 [35.00]	666.8 [26.25]	607	275	130	59	203	92	166	75	108	49	927.1 [36.50]	641.4 [25.25]





Fig. 3 — 38AQS016 Unit Dimensions



LEGEND

- | | | |
|---|---|--------------------------------|
| 1 — Defrost Board/Time Guard II Control | 11 — Power Terminal Block | 21 — Compressor |
| 2 — Fuse | 12 — Control Terminal Block | 22 — Capacity Control Solenoid |
| 3 — Fan No. 1 | 13 — Compressor Lockout (CLO2 for Crankcase Heater) | 23 — Filter Drier |
| 4 — Compressor Lockout Device (CLO) | 14 — Control Relay (CR3) | 24 — Muffler |
| 5 — Outdoor-Fan Relay | 15 — Liquid Line Solenoid | 25 — Oil Solenoid |
| 6 — Outdoor-Fan Contactor | 16 — Control Relay (CR2) | 26 — Reversing Valve |
| 7 — Compressor Contactor | 17 — No Dump Relay (NDR) | 27 — Accumulator |
| 8 — Fan Motor Capacitors | 18 — Oil Pressure Switch | 28 — Coil |
| 9 — Circuit Breaker | 19 — Fusible Plug (hidden) | |
| 10 — Fan No. 2 | 20 — High-Pressure Switch | |

Fig. 4 — Component Locations — 38AQS016 Shown

Table 1A — Physical Data — 38AQ007, 38ARQ008,012, 38AQS016 Units — 60 Hz English

UNIT	38AQ007	38ARQ008	38ARQ012	38AQS016
NOMINAL CAPACITY (tons)	6	7.5	10	15
OPERATING WEIGHTS (lb)				
Aluminum-Fin Coils (standard)	345	464	506	803
Copper-Fin Coils (optional)	N/A	565	607	945
REFRIGERANT*			R-22	
Operating Charge, Typical (lb)†	20	20	22	37
Shipping Charge (lb)	1	9	9	3
COMPRESSOR		Scroll		Semi-hermetic reciprocating
Qty...Model	1...SR_75	1...ZR_94	1...ZR125	1...06DF537††
Oil Charge (oz)	88	90	110	128
No. Cylinders		N/A		6
Speed (rpm)		3500		1750
OUTDOOR FANS				
Qty...Rpm	1...1100	2...1100		2...1075
Diameter (in.)	26	22		26
Nominal Hp	3/4	1/4		1/2
Nominal Airflow (cfm total)	6300	6500		11,000
Watts (total)	750	570		1460
OUTDOOR COILS (Qty)	1	2		1
Face Area (sq ft total)	24	29.2		29.2
Rows...Fins/in.	2...18	2...17		3...15
Storage Capacity (lb)**	17.3	34.2		40.1
CONTROLS				
Pressurestat Settings (psig)				
High Pressure				
Open	420	428 ± 10		395 ± 20
Close	300	320 ± 20		295 ± 20
Low Pressure				
Open	5	7 ± 3		7 ± 3
Close	20	22 ± 5		22 ± 5
PIPING CONNECTIONS (in. ODM)				
Vapor	1 1/8	1 1/8	1 3/8	1 5/8
Liquid	5/8	1/2	1/2	5/8

*Unit is factory supplied with holding charge only.

†Typical operating charge with 25 ft of interconnecting pipe.

**Storage capacity of condenser coil with 80% full of liquid at 95 F.

††Equipped with an electric solenoid unloader, capacity steps 100% and 67%.

Table 1B — Physical Data — 38AQ007, 38ARQ008,012, 38AQS016 Units — 60 Hz SI

UNIT	38AQ007	38ARQ008	38ARQ012	38AQS016
NOMINAL CAPACITY (kW)	21.1	26.4	35.1	52.7
OPERATING WEIGHTS (kg)				
Aluminum-Fin Coils (standard)	157	210	230	365
Copper-Fin Coils (optional)	N/A	256	275	430
REFRIGERANT*	R-22			
Operating Charge, Typical (kg)†	9	9	10	17
Shipping Charge (kg)	.5	4.1	4.1	1.3
COMPRESSOR	Scroll			Semi-hermetic reciprocating
Qty...Model	1...SR_75	1...ZR_94	1...ZR125	1...06DF537††
Oil Charge (L)	2.6	2.7	3.3	3.8
No. Cylinders		N/A		6
Speed (r/s)		58		29
OUTDOOR FANS				
Qty...r/s	1...18	2...18		2...18
Diameter (mm)	660	560		660
Nominal kW	.56	.19		.37
Nominal Airflow (L/s total)	3000	3070		5190
Watts (total)	750	570		1460
OUTDOOR COILS (Qty)	1	2		1
Face Area (sq m total)	2.2	2.7		2.7
Rows...Fins/m	2...708	2...670		3...590
Storage Capacity (kg)**	7.9	15.5		18.2
CONTROLS				
Pressurestat Settings (kPag)				
High Pressure				
Open	2900	2950 ± 70		2725 ± 135
Close	2070	2200 ± 138		2035 ± 135
Low Pressure				
Open	35	48 ± 20		48 ± 20
Close	140	150 ± 35		150 ± 35
PIPING CONNECTIONS (in. ODM)				
Vapor	1 ¹ / ₈	1 ¹ / ₈	1 ³ / ₈	1 ⁵ / ₈
Liquid	5 ₈	1 ₂	1 ₂	5 ₈

*Unit is factory supplied with holding charge only.

†Typical operating charge with 7.6 m of interconnecting pipe.

**Storage capacity of condenser coil with 80% full of liquid at 36 C.

††Equipped with an electric solenoid unloader, capacity steps 100% and 67%.

Table 1C — Physical Data — 38ARQ008,012 and 38AQS016 Units — 50 Hz English

UNIT	38ARQ008	38ARQ012	38AQS016
NOMINAL CAPACITY (tons)	6.3	8.3	12.5
OPERATING WEIGHTS (lb)			
Aluminum-Fin Coils (standard)	464	506	803
Copper-Fin Coils (optional)	565	607	945
REFRIGERANT*	R-22		
Operating Charge, Typical (lb)†	20	22	37
Shipping Charge (lb)	9	9	3
COMPRESSOR	Scroll		Semi-hermetic reciprocating
Qty...Model	1...ZR_94	1...ZR125	1...06DF537††
Oil Charge (oz)	90	110	128
No. Cylinders	N/A		6
Speed (rpm)	2900	2900	1450
OUTDOOR FANS			
Qty...Rpm	2...920		2...900
Diameter (in.)	22		26
Nominal Hp	1/4		1/2
Nominal Airflow (cfm total)	5800		7400
OUTDOOR COILS (Qty)	2		1
Face Area (sq ft total)	29.2		29.2
Rows...Fins/in.	2...17		3...15
Storage Capacity (lb)**	34.2		40.1
CONTROLS			
Pressurestat Settings (psig)			
High Pressure			
Open	428 ± 10		395 ± 20
Close	320 ± 20		295 ± 20
Low Pressure			
Open	7 ± 3		7 ± 3
Close	22 ± 5		22 ± 5
PIPING CONNECTIONS (in. ODM)			
Vapor	1 1/8	1 3/8	1 5/8
Liquid	1/2	1/2	5/8

*Unit is factory supplied with holding charge only.

†Typical operating charge with 25 ft of interconnecting pipe.

**Storage capacity of condenser coil with 80% full of liquid at 95 F.

††Equipped with an electric solenoid unloader, capacity steps 100% and 67%.

Table 1D — Physical Data — 38ARQ008,012 and 38AQS016 Units — 50 Hz SI

UNIT	38ARQ008	38ARQ012	38AQS016
NOMINAL CAPACITY (kW)	22.1	29.2	43.9
OPERATING WEIGHTS (kg)			
Aluminum-Fin Coils (standard)	210	230	365
Copper-Fin Coils (optional)	256	275	430
REFRIGERANT*	R-22		
Operating Charge, Typical (kg)†	9	10	17
Shipping Charge (kg)	4.1	4.1	1.3
COMPRESSOR	Scroll		Semi-hermetic reciprocating
Qty...Model	1...ZR_94	1...ZR125	1...06DF537††
Oil Charge (L)	2.7	3.3	3.8
No. Cylinders	N/A		6
Speed (r/s)	58	58	29
OUTDOOR FANS			
Qty...r/s	2...15		2...15
Diameter (mm)	560		660
Nominal kW	.19		.37
Nominal Airflow (L/s total)	2740		3500
OUTDOOR COILS (Qty)	2		1
Face Area (sq m total)	2.7		2.7
Rows...Fins/m	2...670		3...590
Storage Capacity (kg)**	15.5		18.2
CONTROLS			
Pressurestat Settings (kPag)			
High Pressure			
Open	2950 ± 70		2725 ± 135
Close	2200 ± 138		2035 ± 135
Low Pressure			
Open	48 ± 20		48 ± 20
Close	150 ± 35		150 ± 35
PIPING CONNECTIONS (in. ODM)			
Vapor	1 ¹ / ₈	1 ³ / ₈	1 ⁵ / ₈
Liquid	1 ¹ / ₂	1 ¹ / ₂	5 ¹ / ₈

*Unit is factory supplied with holding charge only.

†Typical operating charge with 7.6 m of interconnecting pipe.

**Storage capacity of condenser coil with 80% full of liquid at 36 C.

††Equipped with an electric solenoid unloader, capacity steps 100% and 67%.

Step 3 — Complete Refrigerant Piping Connections — Refrigerant lines must be carefully designed and constructed to ensure equipment reliability and efficiency. Line length, pressure drop, compressor oil return, and vertical separation are several of the design criteria that must be evaluated. See Table 2.

IMPORTANT: Do not bury refrigerant piping underground.

IMPORTANT: Piping must be properly sized and installed for the system to operate efficiently.

CHECK VERTICAL SEPARATION — If there is any vertical separation between the indoor and outdoor units, check to ensure that the separation is within allowable limits. Relocate equipment if necessary. See Table 3.

REFRIGERANT LINE SIZING — Consider the length of the piping required between the outdoor and indoor units. The maximum allowable line length is 100 ft (30.5 m). See Table 2. Refrigerant vapor piping should be insulated.

IMPORTANT: A refrigerant receiver is not provided with the unit. Do not install a receiver.

IMPORTANT: For 38ARQ008,012 applications with liquid lift greater than 20 ft (6 m), use $\frac{5}{8}$ -in. liquid line. Maximum lift is 60 ft (18 m).

Table 2 — Refrigerant Piping Sizes

OUTDOOR UNIT	LENGTH OF PIPING ft (m)						MAXIMUM LIQUID LINE* (in. OD)
	0-25 (0-7.5)		26-60 (7.8-18.0)		61-100 (18.3-30)		
	Line Size (in. OD)						
	L	V	L	V	L	V	
38AQ007	1/2	11/8	5/8	11/8	5/8	11/8	5/8
38ARQ008	3/8	11/8	1/2	11/8	1/2	11/8	5/8
38ARQ012	1/2	13/8	1/2	13/8	1/2	13/8	5/8
38AQS016	5/8	15/8	3/4	15/8	3/4	15/8	3/4

LEGEND

L — Liquid Line
V — Vapor Line

*If there is a vertical separation between indoor and outdoor units, see Table 3 — Maximum Vertical Separation.

NOTE: Approximately 4 elbows assumed in determining pipe sizes. **Maximum length of interconnecting piping is 100 ft (30.5 m).**

Table 3 — Maximum Vertical Separation*

UNIT 38	UNIT 40RMQ	DISTANCE FT (M)
		Unit 38 Above Unit 40RMQ
AQ007	008	50 (15.2)
ARQ008	008	60 (18.3)
ARQ012	012	60 (18.3)
AQS016	016	80 (24.4)

*Vertical distance between indoor and outdoor units.

INSTALL FILTER DRIER(S) AND MOISTURE INDICATOR(S) — Every unit should have a filter drier and liquid-moisture indicator (sight glass). In some applications, depending on space and convenience requirements, it may be desirable to install 2 filter driers and sight glasses. One filter drier and sight glass may be installed at A locations in Fig. 5. If desired, 2 filter driers and sight glasses may be installed at B locations in Fig. 5.

Select the filter drier for maximum unit capacity and minimum pressure drop. Complete the refrigerant piping from indoor unit to outdoor unit before opening the liquid and vapor lines at the outdoor unit. Refer to Table 4 for specific filter driers.

LIQUID LINE PIPING PROCEDURE — Pipe the system liquid line as follows:


⚠ WARNING

Unit is pressurized with a holding charge of refrigerant. Recover R-22 holding charge before removing runaround liquid piping loop. Failure to recover holding charge before removing piping loop could result in equipment damage and severe personal injury.

- Open service valves in sequence:
 - Discharge service valve on compressor.
 - Vapor service valve on compressor.
 - Liquid line valve.
- Remove $\frac{1}{4}$ -in. flare cap from liquid valve Schrader port.
- Attach refrigerant recovery device and recover holding charge.
- Remove runaround loop (38AQS016 only).
- Connect system liquid line from liquid connection of outdoor unit (38AQ, 38ARQ, 38AQS) to indoor unit (40RMQ) liquid line connections. Select proper field-supplied bi-flow filter driers and install in the liquid line. See Fig. 5. Install a field-supplied liquid moisture indicator between the filter drier(s) and the liquid connections on the indoor unit. Braze or silver alloy solder all connections. Pass nitrogen or other inert gas through piping while making connections to prevent formation of copper oxide. (Copper oxides are extremely active under high temperature and pressure. Failure to prevent collection of copper oxides may result in system component failures.)

LIQUID LINE SOLENOID VALVE — Addition of a liquid solenoid valve (LLSV) is required (except for 38AQS016 units that already have LLSV factory-installed). The LLSV must be a bi-flow type suited for use in heat pump systems. Refer to Table 4 for specific refrigerant specialty parts. Wire the solenoid valve in parallel with the compressor contactor coil.

The LLSV must be installed at the outdoor unit with the flow arrow pointed toward the outdoor unit (in-flow direction for the Heating mode).



LEGEND

TXV — Thermostatic Expansion Valve

Fig. 5 — Location of Sight Glass(es) and Filter Driers

Table 4 — Refrigerant Specialties Part Numbers

UNIT	LIQUID LINE SIZE	LIQUID LINE SOLENOID VALVE (LLSV)	LLSV COIL	SIGHT GLASS	FILTER DRIER
38AQ007	1/2"	200RB GS-1928 5T4	AMG-24/50-60	AMI-1TT4	*
	5/8"	200RB GS-1929 5T5	AMG-24/50-60	AMI-1TT5	*
38ARQ008	3/8"	200RB GS-1928 5T4†	AMG-24/50-60	AMI-1TT3	P504-8083S
	1/2"	200RB GS-1928 5T4	AMG-24/50-60	AMI-1TT4	P504-8084S
38ARQ012	1/2"	200RB GS-1928 5T4	AMG-24/50-60	AMI-1TT4	P504-8164S
38AQS016	5/8"	**	**	AMI-1TT5	P504-8085S Qty 2
	3/4"	**	**	AMI-1TT5	P504-8085S Qty 2

*A filter drier is shipped loose with the 38AQ007.

†Bushings required.

**Factory Installed.

PROVIDE SAFETY RELIEF — A fusible plug is located on the compressor crankcase or in the liquid line. See Fig. 6. Do not cap this plug. If local code requires additional safety devices, install them as directed.

Head Pressure Control (38AQS016 Only) — Fan cycling for head pressure control is a standard offering but is functional in the cooling cycle only. Number 2 fan cycles as a function of liquid pressure. Fan cycling pressure switch cycles the fan off at 160 ± 10 psig (1103 ± 69 kPag) as pressure decreases and cycles back on at 255 ± 10 psig (1758 ± 69). Switch is automatically bypassed in heating cycle. Table 5 shows minimum outdoor air temperature for full cooling capacity without low ambient controls.




Fig. 6 — Location of Fusible Plug — 38AQS016 Unit

Table 5 — Minimum Outdoor Air Operating Temperature

UNIT 38	% COMPRESSOR CAPACITY	MINIMUM OUTDOOR TEMP — F (C)*	
		Standard Unit	Head Pressure Control†
AQ 007	100	0 (–17.8)	0 (–17.8)
ARQ 008		35 (1.7)	–20 (–28.9)
012		35 (1.7)	–20 (–28.9)
AQS 016	100	23 (–5)	–20 (–28.9)
	67	36 (2.2)	–20 (–28.9)

*Applies to Cooling mode of operation only.

†Wind baffles (field-supplied and field-installed) are recommended for all units with low ambient head pressure control. Refer to Low Ambient Control Installation Instructions (shipped with accessory) for details.

VAPOR LINE PIPING PROCEDURE — Connect system vapor line to the vapor line stub on the outdoor unit and the vapor stubs on the indoor unit. At the indoor unit, construct vapor piping branches as shown in Fig. 7 for good mixing of the refrigerant leaving the indoor coil during cooling. This will ensure proper TXV (thermostatic expansion valve) bulb sensing.

Where vapor line is exposed to outdoor air, line must be insulated. See Table 6 for insulation requirements.

Table 6 — Insulation for Vapor Line Exposed to Outdoor Conditions

LENGTH OF EXPOSED VAPOR LINE*		INSULATION THICKNESS†	
ft	m	in.	mm
10	3	3/8	10
25	8	1/2	13
35	11	3/4	19
50	15	3/4	19

*Recommended vapor line insulation for piping exposed to outdoor conditions to prevent loss of heating during heating cycle. When vapor line goes through interior spaces, insulation should be selected to prevent condensation on cooling cycle. Heating capacity should be reduced 1000 Btuh (295 W) if over 35 ft (11 m) of vapor line with 3/4 in. (19 mm) insulation is exposed to outdoor conditions.

†Closed cell foam insulation with a thermal conductivity of: 0.28 Btu • in./ft² • h • °F (0.04 W/m • °C).




Fig. 7 — Vapor Line Branch Piping Details

Step 4 — Complete Electrical Connections

POWER SUPPLY — Electrical characteristics of available power supply must agree with nameplate rating. Supply voltage must be within tolerances shown in Table 7. Phase imbalance must not exceed 2%. *Operation of unit on improper supply voltage or with excessive phase imbalance constitutes abuse and is not covered by Carrier warranty.*

Per local code requirements, provide an adequate fused disconnect switch within sight of unit and out of reach of children. Provision for locking switch open (off) is advisable to prevent power from being turned on while unit is being serviced. The disconnect switch, fuses, and field wiring must comply with local requirements. Refer to Table 7 for electrical data.

POWER WIRING — All power wiring must comply with applicable local requirements. Run power wires from disconnect switch through unit power opening and connect to terminal block inside the unit control box. See Fig. 8-13.

UNBALANCED 3-PHASE SUPPLY VOLTAGE — Never operate a motor where a phase imbalance in supply voltage is greater than 2%. Use the following formula to determine the percentage of voltage imbalance:


$$\% \text{ Voltage Imbalance} = 100 \times \frac{\text{max voltage deviation from average voltage}}{\text{average voltage}}$$

EXAMPLE: Supply voltage is 460-3-60.

$$AB = 452 \text{ v}$$

$$BC = 464 \text{ v}$$

$$AC = 455 \text{ v}$$



$$\begin{aligned} \text{Average Voltage} &= \frac{452 + 464 + 455}{3} \\ &= 457 \text{ v} \end{aligned}$$

Determine maximum deviation from average voltage:

$$(AB) 457 - 452 = 5 \text{ v}$$

$$(BC) 464 - 457 = 7 \text{ v}$$

$$(AC) 457 - 455 = 2 \text{ v}$$

Maximum deviation is 7 v. Determine percentage of voltage imbalance:

$$\begin{aligned} \% \text{ Voltage Imbalance} &= 100 \times \frac{7}{457} \\ &= 1.53\% \end{aligned}$$

This amount of phase imbalance is satisfactory as it is below the maximum allowable of 2%.

IMPORTANT: Contact your local electric utility company immediately if the supply voltage phase imbalance is more than 2%.

⚠ WARNING

Unit cabinet must have an uninterrupted, unbroken electrical ground to minimize the possibility of personal injury if an electrical fault should occur. This ground may consist of electrical wire connected to unit ground lug in control compartment, or conduit approved for electrical ground when installed in accordance with NEC (National Electrical Code) (U.S.A.), ANSI/NFPA (American National Standards Institute/National Fire Protection Association) (U.S.A.), and local electrical codes. Failure to follow this warning could result in the installer being liable for personal injury of others.

IMPORTANT: Operation of unit on improper power supply voltage or with excessive phase imbalance constitutes abuse and is not covered by Carrier warranty.

GENERAL WIRING NOTES (See Fig. 8-13)

1. A crankcase heater is wired in the control circuit so it is always operable as long as power supply disconnect is on, even if any safety device is open or unit stop/start switch is off.

2. The power-circuit field supply disconnect should never be open except when unit is being serviced or is to be down for a prolonged period. When operation is resumed, crankcase heater should be energized for 24 hours before start-up. If system is to be shut down for a prolonged period, it is recommended that the suction and discharge valves be closed to prevent an excessive accumulation of refrigerant in the compressor oil.
3. Terminals for field power supply are suitable for copper, copper-clad aluminum, or aluminum conductors.
4. Carrier recommends an indoor airflow switch (field supplied) be installed and interlocked with the outdoor unit. This prevents the outdoor unit from operating if indoor airflow fails (broken fan belt, etc.). Operation of the compressor in vacuum can damage bearing surfaces. Install indoor airflow switch in a convenient location at the indoor supply air duct and wire per Fig. 14.

CONTROL CIRCUIT WIRING — Control voltage is 24 v. See unit label diagram for field-supplied wiring details. Route control wires through opening in unit end panel to connection in unit control box.

CONTROL TRANSFORMER WIRING — On multivoltage units, check the transformer primary wiring connections. See Fig. 9 or refer to unit label diagram.

For 38AQ, ARQ Units — If unit will be operating at 400-3-50 power, remove the black wire (BLK) from the transformer primary connection labelled “460” and move it to the connection labelled “400”. See Fig. 9.

If unit will be operating at 208-3-60 power, remove black wire (BLK) from the transformer primary connection labelled “230” and move it to the connection labelled “208”. See Fig. 9.

For 38AQS Units — Transformers no. 1 and 2 are wired for a 230-v unit. If a 208/230-v unit is to be run with a 208-v power supply, the transformers must be rewired as follows:

1. Remove cap from red (208 v) wire.
2. Remove cap from orange (230 v) spliced wire.
3. Replace orange wire with red wire.
4. Recap both wires.

IMPORTANT: BE CERTAIN UNUSED WIRES ARE CAPPED. Failure to do so may damage the transformer.

Duplex 38AQS, ARQ with 40RMQ024 or 40RMQ028 — In order to properly connect two heat pump condensing units to a single 40RMQ packaged air handler, it is necessary to add field-supplied Fan Coil Relay Board(s), P/N 33ZCRLYBRD. Relay board(s) no. 1 and no. 2 should be installed in the control box of condensing unit.

IMPORTANT: The common (COM) terminals from the fan coil relay board(s) must be connected to the ‘C’ terminal in condensing unit ‘A’.

Route thermostat cable or equivalent single leads of no. 18 AWG (American Wire Gauge) colored wire from subbase terminals through conduit in unit to low-voltage connections as shown on unit wiring diagram and Fig. 12 and 13.

NOTE: For wire runs up to 50 ft, use no. 18 AWG insulated wire (35 C minimum). For 51 to 75 ft, use no. 16 AWG insulated wire (35 C minimum). For over 75 ft, use no. 14 AWG insulated wire (35 C minimum). All wire larger than no. 18 AWG cannot be directly connected to the thermostat and will require a junction box and a splice at the thermostat.

Table 7 — Electrical Data

UNIT 38	FACTORY-INSTALLED OPTION	NOMINAL VOLTAGE (V-Ph-Hz)	VOLTAGE RANGE*		COMPRESSOR		FAN MOTORS	POWER SUPPLY	
			Min	Max	RLA	LRA	FLA	MCA	MOCP
AQ007	NONE	208/230-3-60	187	253	18.9	146	5.1	28.7	45
		460-3-60	414	506	9.5	73	2.6	14.5	20
		575-3-60	517	633	7.6	58	1.2	10.7	15
ARQ008	NONE OR DISCONNECT	208/230-3-60	187	254	29.0	190	1.5	39.0	60
	CONVENIENCE OUTLET							43.8	60
	NONE OR DISCONNECT	460-3-60	418	506	15.0	95	0.7	19.8	30
	CONVENIENCE OUTLET							21.9	30
	NONE OR DISCONNECT	400-3-50	360	440	15.0	95	0.7	19.8	30
ARQ012	NONE OR DISCONNECT	208/230-3-60	187	254	34.0	225	1.5	45.0	60
	CONVENIENCE OUTLET							50.0	70
	NONE OR DISCONNECT	460-3-60	418	506	17.0	114	0.7	23.0	30
	CONVENIENCE OUTLET							25.0	30
	NONE OR DISCONNECT	575-3-60	523	632	14.0	80	0.7	18.0	25
	CONVENIENCE OUTLET							20.0	25
	NONE OR DISCONNECT	400-3-50	360	440	17.2	125	0.7	22.9	30
AQS016	NONE	208/230-3-60	187	253	63.6	266	4.3	87.5	125
		460-3-60	414	528	29.3	120	2.3	40.7	60
		575-3-60	518	660	23.8	96	1.8	33.0	50
	NONE	230-3-50	198	264	47.9	200	3.5	66.9	100
		400-3-50	342	457	29.3	115	3.5	43.0	60


LEGEND

FLA — Full Load Amps
LRA — Locked Rotor Amps
MCA — Minimum Circuit Amps
MOCP — Maximum Overcurrent Protection
NEC — National Electrical Code (U.S.A. Standard)
RLA — Rated Load Amps

NOTES:

1. The MCA and MOCP values are calculated in accordance with the NEC, Article 440.
2. Motor RLA and LRA values are established in accordance with Underwriters' Laboratories (UL), Standard 1995.
3. The 575-v units are UL, Canada-listed only.
4. Convenience outlet is available as factory-installed option only and is 115-v, 1 ph, 60 Hz.

*Units are suitable for use on electrical systems where voltage supplied to the unit terminals is not below or above the listed limits.



COLOR CODE

BK Black
BL Blue
O Orange
R Red
W White
Y Yellow

NOTES:

1. All electrical work must be done in conformance with the National Electrical Code (NFPA No. 70) and in conformance with local codes and authorities having jurisdiction.
2. For use with copper conductors only.

CAUTION

Not suitable for use on systems exceeding 150 volts to ground.

Fig. 8 — Wiring Diagram — 38AQ007 208/230-3-60 Units




Fig. 9 — Wiring Diagram — 38ARQ008,012 — Control Transformer




Fig. 10 — Wiring Diagram — 38ARQ008,012 230-3-60 Units




Fig. 11 — Wiring Diagram — 38AQS016 Unit With Standard Thermostat and Electric Heat




Fig. 12 — Wiring Diagram — Duplex 38ARQ012 With 40RMQ024 and Electric Heat





Fig. 13 — Wiring Diagram — Duplex 38ARQ012 and 38AQS016 With 40RMQ028 and Electric Heat



NOTES:

1. Locate YEL wire between **Y** on DB and terminal 5 of CR3 and cut.
2. Splice airflow switch (AFS) (field supplied) contact wires (field provided) to two ends of cut YEL wire as depicted.

Fig. 14 — Typical Field Wiring for Airflow Switch — 38AQS016/40RMQ (Shown)

PRE-START-UP

IMPORTANT: Before beginning Pre-Start-Up or Start-Up, review Start-Up Checklist at the back of this book. The checklist assures proper start-up of the system and provides a record of unit condition, application requirements, system information, and operation at initial start-up.

CAUTION

Do not attempt to start the heat pump system, even momentarily, until the following steps have been completed. Compressor damage may result.

Preliminary Checks

1. Check all air handler and other equipment auxiliary components. Consult manufacturer's instructions regarding any other equipment attached to unit. If unit has field-installed accessories, be sure all are properly installed and correctly wired. If used, airflow switch must be properly installed. See Fig. 14 for typical field wiring.
2. As shipped, compressor is held down by 4 bolts. After unit is installed, loosen each bolt using locknut until flat washer or snubber ($\frac{3}{8}$ in.) can be moved with finger pressure. Be sure compressor floats freely on the mounting springs and that upper flat washers can be moved with finger pressure. See Fig. 15A and 15B for compressor mounting.
3. Check tightness of all electrical connections.
4. Ensure electrical power source agrees with nameplate rating.
5. Turn on crankcase heater for 24 hours before starting the unit to be sure all refrigerant is out of the oil. To energize crankcase heater, perform the following steps:
 - a. Set the space thermostat system switch to OFF, or adjust the temperature so there is no demand for cooling.
 - b. Close the field disconnect.
 - c. Leave the compressor circuit breaker off. The crankcase heater is now energized.
6. Leak test the field refrigerant piping, connections and joints, and the indoor coil. To perform leak test, complete the following steps:
 - a. Pressurize refrigerant piping; do not exceed 150 psi.
 - b. Using soap bubbles and/or an electronic leak detector, test refrigerant piping, connections and joints, and the indoor coil. See Fig. 16.

c. Check for leaks.

Evacuate and dehydrate entire refrigerant system by use of methods described in GTAC II, Module 4, System Dehydration.

7. 38AQ016 only — compressor oil level should be visible in sight glass. Adjust the oil level as required. No oil should be removed unless the crankcase heater has been energized for at least 24 hours. See Start-Up section, Preliminary Oil Charge.

NOTE: The 38AQ and 38ARQ units do not have a compressor oil level sight glass. These units are factory charged with the required amount of oil.

If required, use the following oil for replacement: For 38AQ007 use Zerol 150, part number P903-2001. For 38ARQ008,012 use RCD part number P903-0101.




Fig. 15A — Compressor Mounting — 38AQ007 and 38ARQ008,012 Units




Fig. 15B — Compressor Mounting — 38AQ016 Units




Fig. 16 — Recommended Process for Checking for Leaks

- Backseat (open) compressor vapor and discharge valves. Now close valves one turn to allow refrigerant pressure to reach test gages.

Preliminary Charge

⚠ CAUTION

The 38ARQ008 and 38ARQ012 units contain a 9 lb (4.1 kg) charge of refrigerant. Add remainder of preliminary charge and allow pressure to equalize before starting compressor. Failure to do so WILL cause the compressor to overheat in a few minutes, possibly causing permanent compressor damage. **The amount of refrigerant added must be at least 80% of the operating charge listed in the Physical Data table (Tables 1A-1D).**

Before starting the unit, charge liquid refrigerant into the high side of the system through the liquid service valve. Allow high and low side pressures to equalize before starting compressor. If pressures do not equalize readily, charge vapor on low side of system to assure charge in the evaporator. Refer to GTAC II, Module 5, Charging, Recovery, Recycling, and Reclamation for liquid charging procedures.

Liquid Line Solenoid — To minimize refrigerant migration to the compressor during the heat pump OFF cycle, the 38AQ,ARQ unit must have a bi-flow liquid line solenoid valve (field supplied). The valve opens when the compressor is energized, and closes when the compressor is deenergized. This reduces compressor flooded starts, thus significantly increasing compressor life.

Accumulator — The unit accumulator controls the rate of liquid refrigerant to the compressor during heat pump operation.

The 38AQS accumulator features a unique method for returning oil to the compressor. The oil return mechanism is external to the accumulator. The mixture of oil and refrigerant is metered to the compressor by a brass orifice which is removable and cleanable. The oil return mechanism also contains a solenoid valve that opens when the compressor is ON and closes when the compressor is OFF. This keeps the liquid refrigerant stored in the accumulator from draining to the compressor during the heat pump OFF cycle, which further protects the compressor against flooded starts.

START-UP

⚠ CAUTION

Compressor crankcase heater must be on for 24 hours before start-up. After the heater has been on for 24 hours, the unit can be started.

⚠ CAUTION

Prior to starting compressor, a preliminary charge of refrigerant must be added to avoid possible compressor damage.

Compressor Rotation (38AQ,ARQ Units) — On 3-phase units with scroll compressors, it is important to be certain compressor is rotating in the proper direction. To determine whether or not compressor is rotating in the proper direction:

- Connect service gages to suction and discharge pressure fittings.
- Energize the compressor.
- The vapor pressure should drop and the discharge pressure should rise, as is normal on any start-up.

If the vapor pressure does not drop and the discharge pressure does not rise to normal levels:

- Note that the condenser fan is probably also rotating in the wrong direction.


- Turn off power to the unit, tag disconnect.
- Reverse any two of the unit power leads.
- Reapply power to the compressor, verify correct pressures.

The vapor and discharge pressure levels should now move to their normal start-up levels.

Compressor Overload — This overload interrupts power to the compressor when either the current or internal motor winding temperature becomes excessive, and automatically resets when the internal temperature drops to a safe level. This overload usually resets within 60 minutes (or longer). If the internal overload is suspected of being open, disconnect the electrical power to the unit and check the circuit through the overload with an ohmmeter or continuity tester.

Advanced Scroll Temperature Protection (ASTP) — Advanced Scroll Temperature Protection (ASTP) is a form of internal discharge temperature protection that unloads the scroll compressor when the internal temperature reaches approximately 300 F. At this temperature, an internal bi-metal disk valve opens and causes the scroll elements to separate, which stops compression. Suction and discharge pressures balance while the motor continues to run. The longer the compressor runs unloaded, the longer it must cool before the bi-metal disk resets. See Fig. 17.

To manually reset ASTP, the compressor should be stopped and allowed to cool. If the compressor is not stopped, the motor will run until the motor protector trips, which occurs up to 90 minutes later. Advanced Scroll Temperature Protection will reset automatically before the motor protector resets, which may take up to 2 hours. A label located above the terminal box identifies Copeland Scroll compressor models (ZR94, 108 and 125) that contain this technology. See Fig. 18.



*Times are approximate. Various factors, including high humidity, high ambient temperature, and the presence of a sound blanket will increase cool-down times.

Fig. 17 — Recommended Minimum Cool-Down Time After Compressor is Stopped*



Fig. 18 — Advanced Scroll Temperature Protection Label

Compressor Lockout (CLO) Device — The Compressor lockout (CLO) device prevents the compressor from starting or running in a high pressure, loss-of-charge or freestat open situation. Reset the CLO device by setting the thermostat to eliminate cooling demand and return it to the original set point. If the system shuts down again for the same fault, determine the possible cause before attempting to reset the CLO device.

Preliminary Oil Charge (38AQS) — The compressor is factory charged with oil (see Tables 1A-1D). When oil is checked at start-up, it may be necessary to add or remove oil to bring it to the proper level. Add oil only if necessary to bring oil into view in sight glass. *Use only Carrier-approved compressor oil.* One recommended oil level adjustment method is as follows:

ADD OIL — Close vapor service valve and pump down crankcase to 2 psig. Wait a few minutes and repeat until pressure remains steady at 2 psig. Remove oil fill plug above the sight glass, add oil through plug hole, and replace plug. Run compressor for 20 minutes and check oil level.

NOTE: Use only Carrier approved compressor oil. Approved sources are:

Petroleum Specialties, Inc..... Cryol 150A
 Texaco, Inc..... Capella WF32
 Witco Chemical Co..... Suniso 3GS

Do not use oil that has been drained out, or oil that has been exposed to atmosphere.

REMOVE OIL — Pump down compressor to 2 psig. Loosen the 1/4-in. pipe plug at the compressor base and allow the oil to seep out past the threads of the plug. Retighten plug when level is correct.

NOTE: The crankcase is slightly pressurized. Do not remove the plug, or the entire oil charge will be lost.

Small amounts of oil can be removed through the oil pump discharge connection while the compressor is running.

Start Unit — The field disconnect is closed, the fan circuit breaker is closed, and the space thermostat is set above ambient so that there is no demand for cooling. Only the crankcase heater will be energized.

Next, close the compressor circuit breaker and then reset space thermostat below ambient so that a call for cooling is ensured.

NOTE: Do not use circuit breaker to start and stop the compressor except in an emergency.

After starting, there is a delay of at least 3 seconds before compressor starts.

Adjust Refrigerant Charge — Refer to Charging Charts Fig. 19A-19C and Table 8. Do not exceed maximum refrigerant charge. Vary refrigerant until the conditions of the chart are met. Note that charging charts are different from type normally used. Charts are based on charging the units to the correct subcooling for the various operating conditions. Accurate pressure gage and temperature sensing device are required.

Connect the pressure gage to the service port on the liquid line service valve. Mount the temperature sensing device on the liquid line, close to the liquid line service valve and insulate it so that outdoor ambient temperature does not affect the reading. Indoor airflow must be within the normal operating range of the unit. Operate unit a minimum of 15 minutes. Ensure pressure and temperature readings have stabilized. Plot liquid pressure and temperature on chart and add or reduce charge to meet curve. Adjust charge to conform with charging chart, using the liquid pressure and temperature to read chart.

If the sight glass is cloudy, check refrigerant charge again. *Ensure all fans are operating.* Also ensure maximum allowable liquid lift has not been exceeded. If charged per chart and if the sight glass is still cloudy, check for a plugged filter drier or a partially closed solenoid valve. Replace or repair, as needed.




Fig. 19A — 38AQ007 Charging Chart




Fig. 19B — 38ARQ008,012 Charging Chart




Fig. 19C — 38AQS016 Charging Chart

⚠ CAUTION

Never charge liquid into the low-pressure side of system. Do not overcharge. During charging or removal of refrigerant, be sure indoor-fan system is operating.

⚠ CAUTION

Charge unit on cooling cycle only. If unit is charged on heating cycle, overcharging may occur.

Checking Heating Cycle Operation — Place thermostat selector switch at HEAT and reset the space set point above ambient temperature so that a call for heating is ensured. Compressor will start within 5 minutes. Observe system operation.

Check Compressor Oil Level (38AQS) — After adjusting the refrigerant charge, allow the system to run fully loaded for 20 minutes. Running oil level should be within view in the crankcase sight glass. Stop compressor at the field power supply disconnect and check the crankcase oil level. Add oil only if necessary to bring the oil into view in the sight glass. If oil is added, run the system for an additional 10 minutes, then stop and check oil level. If the level remains low, check the piping system for proper design for oil return; also check the system for leaks.

If the initial check shows too much oil (too high in the sight glass) remove oil to proper level. See Preliminary Oil Charge section for proper procedure for adding and removing oil.

When the above checks are complete, repeat the procedure with the unit operating at minimum load conditions. Unload the compressor by disconnecting the field-control circuit lead at TB2 **Y2**.

Reconnect the field-control circuit lead when checks are complete.

Final Checks — Ensure all safety controls are operating, control panel covers are on, and the service panels are in place.

Table 8 — Maximum Refrigerant Charge

UNIT 38	R-22	
	(lb)	(kg)
AQ007	27.0	12.2
ARQ008,012	34.2	15.5
	34.2	15.5
AQS016	62.0	28.1

SEQUENCE OF OPERATION

38AQ007 Units — When power is supplied to unit, the transformer (TRAN) and crankcase heater (CCH) are energized.

COOLING — On a call for cooling, the thermostat completes the following circuits: R-G, R-Y, and R-O. If the compressor recycle delay of 3 minutes is complete, the compressor and outdoor fan start. The reversing valve is energized for cooling and the indoor-fan motor starts.

When the thermostat is satisfied, the circuits are opened, and the compressor, outdoor-fan motor, and indoor-fan motor stop. The reversing valve is deenergized.

HEATING — On a call for heating, the thermostat completes the following circuits: R-G and R-Y. If the compressor recycle delay of 3 minutes is complete, the compressor and outdoor fan start. The indoor-fan motor will also start.

If room temperature continues to fall, the thermostat completes circuit R-W. If the optional electric heat package is used, the heat relay is energized, and the electric heaters are energized.

When the thermostat is satisfied, the circuits are opened, and the compressor, outdoor-fan motor, heaters, and indoor-fan motor stop.

DEFROST — Defrost board (DB) is a time and temperature control, which includes a field-selectable time period between checks for frost (30, 50, and 90 minutes). Electronic timer and defrost cycle start only when contactor is energized and defrost thermostat (DFT) is closed (below 28 F [−2.2 C]).

Defrost mode is identical to Cooling mode, except outdoor-fan motor (OFM) stops and a bank of supplemental electric heat turns on to warm air supplying the conditioned space. Defrost mode is terminated when the DFT reaches 65 F (18.3 C).

AIR CIRCULATION — When the fan switch is at FAN ON, the indoor-air fans operate continuously to provide ventilation. The thermostat operates the other components as described above.

EMERGENCY HEAT CYCLE — If the compressor is inoperative due to a tripped safety device, the second stage of the thermostat automatically energizes the indoor-air fan and the electric resistance heaters (if equipped).

38ARQ008,012 Units — When power is supplied to unit, the transformer (TRAN) is energized. The crankcase heater is also energized.

COOLING — With the thermostat subbase in the cooling position, and when the space temperature comes within 2° F (1° C) of the cooling set point, the thermostat makes circuit R-O. This energizes the reversing valve solenoid (RVS) and places the unit in standby condition for cooling.

As the space temperature continues to rise, the second stage of the thermostat makes, closing circuit R-Y. When compressor time delay (5 ± 2 minutes) is completed, a circuit is made to contactor (C), starting the compressor (COMP) and outdoor-fan motor (OFM). Circuit R-G is made at the same time, energizing the indoor-fan contactor (IFC) and starting the indoor-fan motor (IFM) after one-second delay.

When the thermostat is satisfied, contacts open, deenergizing C. The COMP, IFM, and OFM stop.

HEATING — On a call for heat, thermostat makes circuits R-Y and R-G. When compressor time delay (5 ± 2 minutes) is completed, a circuit is made to C, starting COMP and OFM. Circuit R-G also energizes IFC and starts IFM after a 1-second delay.

38AQS016 Units

HEATING — Place thermostat selector at HEAT and set temperature selector above room ambient.

COOLING — Place thermostat selector at COOL and set temperature selector below room ambient.

When thermostat calls for unit operation (either heating or cooling), the indoor-fan motor starts immediately. The outdoor-fan motors and compressor start within 3 seconds to 5 minutes depending on when unit was last shut off by thermostat, because unit contains a compressor time delay circuit. When first-stage cooling is required, thermostat (TC1) closes, causing the heat pump to start with an unloaded compressor. When TC2 closes, demanding additional cooling, the compressor loads to full load operation.

During heating, compressor is always fully loaded. When TH1 demands first-stage heating, the heat pump starts within 3 seconds to 5 minutes depending on when unit was last shut off by thermostat, because unit contains a compressor time delay circuit. (The defrost board has speed terminals to shorten this cycle.) When TH2 of the thermostat closes, auxiliary heat supply (electric strip heat) is energized in 1 or 2 stages depending on number of stages available and whether outdoor thermostats are closed.

Defrost is achieved by reversal from heating to cooling cycle and deenergization of outdoor-fan motors, allowing hot refrigerant gas to defrost outdoor coil. Defrost is achieved with a timer set to initiate defrost every 30, 50, or 90 minutes (factory set at 30 minutes).

Defrost is initiated when refrigerant temperature leaving the outdoor coil is measured below 27 F (2.8 C), (typically when the outdoor ambient temperature is below 45 F [7.2 C] as sensed by the defrost thermostat [DFT]).

Defrost is terminated when: The refrigerant temperature rises to 65 F (18.3 C) (80 F [26.7 C] for 38AQS016) at the DFT location on the liquid line; or the refrigerant pressure rises to 280 psig (1931 kPag) at the HPS2 location on the liquid line; or the defrost timer completes the 10-minute cycle.

Duplex Units

DUPLEX 38ARQ012 UNITS WITH 40RMQ024 (See Fig. 12)

Cooling — When the thermostat is set for cooling, and the space temperature comes within 2° F (1° C) of the cooling set point, the thermostat completes the circuit from R to O and the reversing valves in both units are energized. If the space temperature continues to rise, the circuit from R to Y1 is completed. If the time delays and safeties are satisfied, the compressor contactor closes, starting the compressor and outdoor-fan motors of Heat Pump A. At the same time the circuit is completed from R to G, starting the indoor-fan motor. If the space temperature continues to rise, the circuit is completed from R to Y2 and the Cooling mode is initiated in Heat Pump B in a similar manner.

When the thermostat is satisfied, the contacts open, deenergizing first the Heat Pump B and then Heat Pump A.

Heating — When the thermostat calls for heating, the circuit from R to Y1 is completed. If the time delays and safeties are satisfied, the compressor contactor closes, starting the compressor and outdoor-fan motors of Heat Pump A and Heat Pump B. At the same time the circuit is completed from R to G, starting the indoor-fan motor. If the second stage of heating is required, the circuit from R to W2 will be completed and the electric resistance heaters will be energized.

When the thermostat is satisfied, the contacts open, deenergizing Heat Pump A and Heat Pump B.

DUPLEX 38AQS016 AND 38ARQ012 UNITS WITH 40RMQ028 (See Fig. 13)

Cooling — When the thermostat calls for cooling, the circuit from R to Y1 is completed. If the time delays and safeties are satisfied, the compressor contactor closes, starting the compressor and outdoor-fan motors of Heat Pump A (38AQS016). At the same time the circuit is completed from R to G, starting the indoor-fan motor. If the space temperature continues to rise, the circuit is completed from R to Y2 and the Cooling mode is initiated in Heat Pump B (38ARQ012).

When the thermostat is satisfied, the contacts open, deenergizing first the Heat Pump B and then Heat Pump A.

Heating — When the thermostat calls for heating, the circuit from R to W1 is completed. If the time delays and safeties are satisfied, the compressor contactor closes, starting the compressor and outdoor-fan motors of Heat Pump A and Heat Pump B. At the same time the circuit is completed from R to G, starting the indoor-fan motor. If the second stage of heating is required, the circuit from R to W2 will be completed and the electric resistance heaters will be energized.

When the thermostat is satisfied, the contacts open, deenergizing Heat Pump A and Heat Pump B.

SAFETIES — The high-pressure switch, loss-of-charge switch, oil pressure safety switch, and compressor overtemperature safety are located in a CLO that prevents heat pump operation if these safety devices are activated. The lockout

system can be reset by adjusting the thermostat to open the contacts (down for Heating mode, up for Cooling mode), deenergizing the CLO. Compressor overcurrent protection is achieved with a circuit breaker which requires manual resetting at the outdoor unit control box (38AQS only).

The 38AQS unit is equipped with an oil pressure safety switch that protects the compressor if oil pressure does not develop on start-up or is lost during operation. The oil pressure switch is of the manual reset type and therefore must be reset at the outdoor unit. **DO NOT RESET MORE THAN ONCE.**

If oil pressure switch trips, determine cause and correct. **DO NOT JUMPER OIL PRESSURE SAFETY SWITCH.**

To reset the oil pressure switch:

1. Disconnect power to the unit.
2. Press the RESET button on the oil pressure switch.
3. Reconnect power to the unit.

Unit is equipped with a no-dump reversing valve circuit. When unit is in Cooling mode, reversing valve remains in cooling position until a call for heating is requested by thermostat. When unit is in Heating mode, reversing valve remains in heating position until there is a call for cooling.

CHECK OPERATION — Ensure operation of all safety controls. Replace all service panels. *Be sure that control panel cover is closed tightly.*

Restart — Manual reset of the 24-v control circuit is necessary if unit shutdown is caused by automatic reset devices (including IP [internal compressor overcurrent protection], HPS [high-pressure switch], LCS [loss-of-charge switch]), or if shutdown is caused by manual reset devices (including OPS [oil pressure switch] and compressor circuit breaker protection). To restart the unit when IP, HPS, or LCS has tripped (*after device has reset automatically*), open and then close the thermostat contacts. Opening and then closing thermostat contacts interrupts and restores 24-v power to the CLO, which resets the circuit.

It is necessary to manually reset the compressor circuit breaker and OPS at the unit if either of these safeties should shut down the unit.

IMPORTANT: If OPS trips, it must be reset **first** before making and breaking the thermostat contacts to reset CLO. If this procedure is not followed, the CLO cannot reset.

Causes of Complete Unit Shutdown:

- interruption of supplied power
- open compressor overtemperature protection (IP)
- compressor electrical overload protection (CB)
- open high-pressure or loss-of-charge safety switches
- open oil pressure switch
- open crankcase heater lockout (CLO2)
- open control circuit fuse (FU1 or FU2)
- open discharge gas thermostat (38ARQ only)

SERVICE

Compressor Removal — See Tables 1A-1D for compressor information. Follow safety codes and wear safety glasses and work gloves.

1. Shut off power to unit. Remove unit access panel.
2. Recover refrigerant from system using refrigerant recovery methods described in Carrier Training booklet GTAC II, Module 5, and in accordance with local and national standards.
3. Disconnect compressor wiring at compressor terminal box.
4. Disconnect refrigerant lines from compressor.

- Remove screws from compressor mounting plate.

⚠ CAUTION

Excessive movement of copper lines at compressor may cause higher levels of vibration when unit is restored to service.

- Remove or disconnect crankcase heater from compressor base.
- Remove compressor from unit.
- On 38AQS016 unit remove compressor holddown bolts and lift compressor off mounting plate.
- Clean system. Add new liquid line filter drier.
- Install new compressor on compressor mounting plate and position in unit. Connect vapor and discharge lines to compressor. Secure mounting plate with compressor to unit. Ensure that compressor holddown bolts are in place. Connect wiring. Install crankcase heater.
- Evacuate and recharge unit.
- Restore unit power.

38ARQ008, 012 Cooling Mode Operation (See Fig. 20)

- High pressure, high temperature refrigerant vapor from the compressor flows through the reversing valve and is directed to the vapor headers of both outdoor coils.
- At the outdoor coil vapor header, the high pressure, high temperature refrigerant vapor flows up to check valve "A" that blocks the flow. All the refrigerant is then directed to flow into the coil circuits.

- Subcooled refrigerant liquid leaves the coil circuits through the side outlet on the liquid headers. The liquid refrigerant from each coil flows through check valves "B" which are open, enters the liquid line and goes to the indoor coil.
- The liquid refrigerant is expanded and evaporated in the indoor coil resulting in low pressure vapor. This low pressure vapor returns to the outdoor unit through the system vapor line, reversing valve, and accumulator, reentering the compressor at the suction connection.

38ARQ008, 012 Heating Mode Operation (See Fig. 21)

- High pressure, high temperature refrigerant vapor from the compressor flows through the reversing valve and is directed through the system vapor line to the indoor coil. Refrigerant is condensed and subcooled in the indoor coil and returns to the outdoor unit through the system liquid line.
- Check valve "B" blocks the flow of liquid and the liquid refrigerant must flow through the filter driers, through check valve "C", and into the liquid header assembly.
- The liquid refrigerant is expanded as it passes through the fixed orifice metering devices into outdoor coil circuits. The refrigerant evaporates as it passes through the coil circuits resulting in low pressure vapor.
- The low pressure vapor leaves the coil circuits and enters the vapor headers, check valves "A" are open, and returns to the compressor through the vapor line, reversing valve, and accumulator, reentering the compressor at the suction connection.




Fig. 20 — 38ARQ008, 012 Cooling Mode (Size 008 Shown)




Fig. 21 — 38ARQ008, 012 Heating Mode (Size 008 Shown)

38AQS016 Cooling Mode Operation (See Fig. 22)

1. High pressure, high temperature refrigerant vapor from the compressor flows through the reversing valve and is directed to the outdoor coil vapor header.
2. At the outdoor coil vapor header, the high pressure, high temperature refrigerant vapor flows up to check valve "A" that blocks the flow. All the refrigerant is then directed to flow into the coil circuits.
3. Subcooled refrigerant liquid leaves the coil circuits entering the portion of the vapor header which is above check valve "A". Check valve "C" is closed, therefore, the liquid refrigerant passes through check valve "B," which is open, and enters the liquid line and goes to the indoor coil.
4. The liquid refrigerant is expanded and evaporated in the indoor coil resulting in low pressure vapor. This low pressure vapor returns to the outdoor unit through the system vapor line, reversing valve, and accumulator, reentering the compressor at the suction connection.

38AQS016 Heating Mode Operation (See Fig. 23)

1. High pressure, high temperature refrigerant vapor from the compressor flows through the reversing valve and is directed through the system vapor line to the indoor coil. Refrigerant is condensed and subcooled in the indoor coil and returns to the outdoor unit through the system liquid line.

2. Check valve "B" blocks the flow of liquid and the refrigerant is then directed to flow through check valve "C" (which is open), through the filter drier, and into the liquid header assembly.
3. The liquid refrigerant is expanded as it passes through the capillary tubes into outdoor coil circuits. The refrigerant evaporates as it passes through the coil circuits resulting in low pressure vapor.
4. The low pressure vapor leaves the coil circuits and enters the vapor header, check valve "A" is open, and returns to the compressor through the vapor line, reversing valve, and accumulator, reentering the compressor at the suction connection.

Crankcase Heater — The crankcase heater prevents refrigerant migration and compressor oil dilution during shutdown when compressor is not operating.

Close both compressor service valves when crankcase heater is deenergized for more than 6 hours.

Outdoor Unit Fans — Each fan is supported by a formed-wire mount bolted to the fan deck and covered with a wire guard. On the 38AQS016, the exposed end of the motor shaft is covered with a rubber boot. In case a fan motor must be repaired or replaced, be sure the rubber boot is put back on when the fan is reinstalled and be sure the fan guard is in place before starting the unit.

Lubrication — Fan motors have permanently sealed bearings. No further lubrication is required.




Fig. 22 — 38AQS016 Cooling Mode




Fig. 23 — 38AQS016 Heating Mode

Coil Cleaning and Maintenance — This section discusses the cleaning and the maintenance of standard coils and E-Coated coils. Routine cleaning of coil surfaces is essential to minimize contamination build-up and remove harmful residue. Inspect coils monthly and clean as required.

CLEANING STANDARD COILS — Standard coils can be cleaned with a vacuum cleaner, washed out with low velocity water, blown out with compressed air, or brushed (*do not use wire brush*). Fan motors are drip-proof but not waterproof. Do not use acid cleaners.

Clean coil annually or as required by location or outdoor air conditions. Inspect coil monthly and clean as required. Fins are not continuous through coil sections. Dirt and debris may pass through first section and become trapped, restricting condenser airflow. Use a flashlight to determine if dirt or debris has collected between coil sections.

Clean coils as follows:

1. Turn off unit power.
2. Remove screws holding rear corner posts and top cover in place. Pivot top cover up 12 to 18 in. (300 to 450 mm) and support with a board or other adequate rigid support. See Fig. 24.
3. Remove clips securing tube sheets together at the return bend end of the coil. Carefully spread the ends of the coil rows apart by moving the outer sections. See Fig. 25.
4. Using a water hose or other suitable equipment, flush down between the sections of coil to remove dirt and debris.
5. Clean the remaining surfaces in the normal manner.
6. Reposition outer coil sections. Reinstall clips which secure tube sheets, and replace top cover and rear corner posts.
7. Restore unit power.

CLEANING AND MAINTAINING E-COATED COILS — Routine cleaning of condenser coil surfaces is essential to maintain proper operation of the unit. Elimination of contamination and removal of harmful residue will greatly increase the life of the coil and extend the life of the unit. The following maintenance and cleaning procedures are recommended as part of the routine maintenance activities to extend the life of the coil.




Fig. 24 — Pivot and Support Top Cover




Fig. 25 — Coil Cleaning (Typical)

Remove Surface Loaded Fibers — Debris such as dirt and fibers on the surface of the coil should be removed with a vacuum cleaner. If a vacuum cleaner is not available, a soft brush may be used. The cleaning tool should be applied in the direction of the fins. Coil surfaces can be easily damaged (fin edges bent over) if the tool is applied across the fins.

NOTE: Use of a water stream, such as a garden hose, against a surface loaded coil will drive the fibers and dirt into the coil. This will make cleaning efforts more difficult. Surface debris must be completely removed prior to using low velocity clean water rinse.

Periodic Clean Water Rinse — A periodic clean water rinse is very beneficial for coils that are applied in coastal or industrial environments. However, it is very important that the water rinse is made with very low velocity water stream to avoid damaging the fin edges. Monthly cleaning is recommended.

Routine Cleaning of E-Coated Coil Surfaces — Monthly cleaning with Environmentally Sound Coil Cleaner is essential to extend the life of coils. It is recommended that all coils including standard aluminum, pre-coated, copper/copper, or E-coated coils be cleaned with the Environmentally Sound Coil Cleaner as described below. Coil cleaning should be part of the regularly scheduled maintenance procedures of the unit to ensure long life of the coil. Failure to clean the coils may result in reduced durability in the environment.

Environmentally Sound Coil Cleaner is non-bacterial, biodegradable and will not harm the coil or surrounding components such as electrical wiring, painted metal surfaces or insulation. Use of non-recommended coil cleaners is strongly discouraged since coil and unit durability could be affected.

The following field supplied equipment is required for coil cleaning:

- 2½ gallon (9.5 liter) garden sprayer
- water rinse with low velocity spray nozzle

Environmentally Sound Coil Cleaner Application Instructions — Perform the following procedure to clean the coil.

NOTE: Wear proper eye protection such as safety glasses during mixing and application.

1. Remove all surface debris and dirt from the coil with a vacuum cleaner.
2. Thoroughly wet finned surfaces with clean water and a low velocity garden hose, being careful not to bend fins.
3. Mix Environmentally Sound Coil Cleaner in a 2½ gallon (9.5 liter) garden sprayer according to the instructions included with the cleaner. The optimum solution temperature is 100 F (37.8 C).

⚠ CAUTION

DO NOT USE water in excess of 130 F (54.4 C). Enzymes in coil cleaner will be destroyed and coil cleaner will not be effective.

4. Thoroughly apply Environmentally Sound Coil Cleaner solution to all coil surfaces including finned area, tube sheets, and coil headers. Hold garden sprayer nozzle close to finned areas and apply cleaner with a vertical, up-and-down motion. Avoid spraying in horizontal pattern to minimize potential for fin damage. Ensure cleaner thoroughly penetrates deep into finned areas. Interior and exterior finned areas must be thoroughly cleaned.
5. Allow finned surfaces to remain wet with cleaning solution for 10 minutes. Ensure surfaces are not allowed to dry before rinsing. Reapply cleaner as needed to ensure 10-minute saturation is achieved.


6. Thoroughly rinse all surfaces with low velocity clean water using downward rinsing motion of water spray nozzle. Protect fins from damage from the spray nozzle.

⚠ CAUTION


Do not use bleach, harsh chemicals, or acid cleaners on outdoor or indoor coils of any kind. These types of cleaners are difficult to rinse, and they promote rapid corrosion of the fin collar — copper tube connection. Only use the Environmentally Sound Coil Cleaner.

Never use high pressure air or liquids to clean coils. High pressures damage coils and increase the airside pressure drop. To promote unit integrity, follow cleaning and maintenance procedures in this document.

TROUBLESHOOTING CHART — HEATING CYCLE



TROUBLESHOOTING CHART — COOLING CYCLE



START-UP CHECKLIST

I. PRELIMINARY INFORMATION

OUTDOOR UNIT: MODEL NO. _____ SERIAL NO.: _____
INDOOR UNIT: MODEL NO. _____ SERIAL NO.: _____
ADDITIONAL ACCESSORIES _____

II. PRE-START-UP

OUTDOOR UNIT

IS THERE ANY SHIPPING DAMAGE? (Y/N) _____

IF SO, WHERE: _____

WILL THIS DAMAGE PREVENT UNIT START-UP? (Y/N) _____

CHECK POWER SUPPLY. DOES IT AGREE WITH UNIT? (Y/N) _____

HAS THE GROUND WIRE BEEN CONNECTED? (Y/N) _____

HAS THE CIRCUIT PROTECTION BEEN SIZED AND INSTALLED PROPERLY? (Y/N) _____

ARE THE POWER WIRES TO THE UNIT SIZED AND INSTALLED PROPERLY? (Y/N) _____

HAVE COMPRESSOR HOLDDOWN BOLTS BEEN LOOSENEED (Snubber washers are snug, but not tight)?
(Y/N) _____

CONTROLS

ARE THERMOSTAT AND INDOOR FAN CONTROL WIRING
CONNECTIONS MADE AND CHECKED? (Y/N) _____

ARE ALL WIRING TERMINALS (including main power supply) TIGHT? (Y/N) _____

HAS CRANKCASE HEATER BEEN ENERGIZED FOR 24 HOURS? (Y/N) _____

INDOOR UNIT

HAS WATER BEEN PLACED IN DRAIN PAN TO CONFIRM PROPER DRAINAGE? (Y/N) _____

ARE PROPER AIR FILTERS IN PLACE? (Y/N) _____

HAVE FAN AND MOTOR PULLEYS BEEN CHECKED FOR PROPER ALIGNMENT? (Y/N) _____

DO THE FAN BELTS HAVE PROPER TENSION? (Y/N) _____

HAS CORRECT FAN ROTATION BEEN CONFIRMED? (Y/N) _____

PIPING

HAVE LEAK CHECKS BEEN MADE AT COMPRESSOR, OUTDOOR UNIT, INDOOR UNIT,
TXVs (Thermostatic Expansion Valves), SOLENOID VALVES, FILTER DRIERS, AND FUSIBLE
PLUGS WITH A LEAK DETECTOR? (Y/N) _____

LOCATE, REPAIR, AND REPORT ANY LEAKS. _____

HAVE ALL COMPRESSOR SERVICE VALVES BEEN FULLY OPENED (BACKSEATED)? (Y/N) _____

HAS LIQUID LINE SERVICE VALVE BEEN OPENED? (Y/N) _____

IS THE OIL LEVEL IN COMPRESSOR CRANKCASE VISIBLE IN THE COMPRESSOR SIGHT GLASS?
(Y/N) _____

CHECK VOLTAGE IMBALANCE

LINE-TO-LINE VOLTS: AB _____ V AC _____ V BC _____ V

$(AB + AC + BC)/3 = \text{AVERAGE VOLTAGE} = \text{_____ V}$

MAXIMUM DEVIATION FROM AVERAGE VOLTAGE = _____ V

VOLTAGE IMBALANCE = $100 \times (\text{MAX DEVIATION})/(\text{AVERAGE VOLTAGE}) = \text{_____ \%}$

IF OVER 2% VOLTAGE IMBALANCE, DO NOT ATTEMPT TO START SYSTEM!

CALL LOCAL POWER COMPANY FOR ASSISTANCE.

III. START-UP

CHECK INDOOR FAN SPEED AND RECORD. _____

CHECK OUTDOOR FAN SPEED AND RECORD. _____

AFTER AT LEAST 10 MINUTES RUNNING TIME, RECORD THE FOLLOWING MEASUREMENTS:

OIL PRESSURE

VAPOR PRESSURE

VAPOR LINE TEMP

DISCHARGE PRESSURE

DISCHARGE LINE TEMP

ENTERING OUTDOOR AIR

LEAVING OUTDOOR AIR TEMP

INDOOR ENTERING-AIR DB (dry bulb) TEMP

INDOOR ENTERING-AIR WB (wet bulb) TEMP

INDOOR LEAVING-AIR DB TEMP

INDOOR LEAVING-AIR WB TEMP

COOLING

HEATING

COMPRESSOR AMPS (L1/L2/L3) _____ / _____ / _____

CHECK THE COMPRESSOR OIL LEVEL SIGHT GLASSES; ARE THE SIGHT GLASSES SHOWING OIL LEVEL IN VIEW? (Y/N)

NOTES:

CUT ALONG DOTTED LINE

CUT ALONG DOTTED LINE